

- **I am getting read/write errors on my SD card inserted into the MicroSD slot of the Vampire.**
  - Your SD card might be bad / damaged. Try a different one.
  - The adapters and cables between the MicroSD slot and your SD card might be bad / damaged. Try different ones.
  - The SD card might have been prepared incorrectly. Try using it on a different Amiga (or on an Amiga emulator) to make sure it is set up correctly.
  - Try formatting the SD card and preparing it from scratch.
  - If you have an extension cable, it might be too long. Try a shorter one.
  - The MicroSD speed might have been set to a level that is too much for your configuration, especially if your extension cable is too long. Use the `VControl SDSPEED` command to set a lower speed level.

From:  
<https://wiki.apollo-accelerators.com/> - **Apollo Accelerators**

Permanent link:  
[https://wiki.apollo-accelerators.com/doku.php/vampire:microsd\\_troubleshooting?rev=1581561082](https://wiki.apollo-accelerators.com/doku.php/vampire:microsd_troubleshooting?rev=1581561082)

Last update: **2020/08/02 12:37**

